SM SOLAR MOUNT

# INSTALLATION GUIDE




## UNIRAC Code-Compliant Installation Manual

© 2022 by Unirac, Inc. All rights reserved.

**UNIRAC welcomes input concerning the accuracy and user-friendliness of this publication. Please write to publications@unirac.com.**

**PUB2026JUL20**

SM SOLAR MOUNT

# INSTALLATION GUIDE

## TABLE OF CONTENTS

### PRO SERIES SYSTEM


PRO SERIES SYSTEM COMPONENTS . . . . . 1
SYSTEM COMPONENTS . . . . . 2-4
THERMAL BREAK . . . . . 5
SYSTEM LAYOUT . . . . . 6
ROOF ATTACHMENT & L-FEET . . . . . 7
SPLICE . . . . . 8
ATTACH RAIL TO L-FEET . . . . . 9
MICROINVERTER MOUNTING . . . . . 10
MICROINVERTER SYSTEM GROUNDING . . . . . 11
SPLICE & THERMAL BREAK . . . . . 12
STANDARD SYSTEM GROUNDING . . . . . 13-15
ENDCLAMP, FIRST MODULE . . . . . 16
BONDING MIDCLAMP . . . . . 17
REMAINING MODULES . . . . . 18
BONDING CONNECTION GROUND PATHS . . . . . 19-20
TRIM AND END CAP INSTALLATION . . . . . 21



### STANDARD SERIES SYSTEM


SYSTEM COMPONENTS . . . . . 22
END & MID CLAMPS . . . . . 23
ATTACH RAIL TO L-FEET . . . . . 24
ENDCLAMP & FIRST MODULE . . . . . 25
BONDING MIDCLAMP & TRIM . . . . . 26
REMAINING MODULES & TRIM . . . . . 27
TRIM RETROFIT INSTALLATION . . . . . 28
BONDING CONNECTION GROUND PATHS . . . . . 29-30
CODE COMPLIANCE NOTES . . . . . 31
MECHANICAL LOAD TEST . . . . . 32
SYSTEM LEVEL FIRE CLASSIFICATION . . . . . 33
COMPATIBLE MODULES . . . . . 34-39
APPENDIX A: FLASHKIT PRO INSTALLATION . . . . . 40
APPENDIX B: FLASHLOC COMP INSTALLATION . . . . . 41
APPENDIX C: FLASHLOC DUO INSTALLATION . . . . . 42
APPENDIX D: UAF END & MID CLAMP INSTALLATION . . . . . 43-44
APPENDIX E: S-5! COMPONENTS INSTALLATION . . . . . 45-47
APPENDIX F: SM BUTYL ATTACHMENT INSTALLATION . . . . . 48-55

# PRO SERIES SYSTEM COMPONENTS

## INSTALLATION GUIDE






❶**RAIL**: Supports PV modules. Use at least two per row of modules. Aluminum extrusion, available in mill, clear anodized, or dark anodized.

❷❸**RAIL SPLICE**: Non structural splice joins, aligns, and electrically bonds rail sections into single length of rail. Forms a rigid splice joint, 4 inches long, preassembled with bonding hardware. Available in dark anodized or mill finish.

❹**L-FOOT**: Use to secure rails through roofing material to building structure. Refer to loading tables or U-Builder for spacing.

❺ **L-FOOT T- BOLT**: (3/8" x ¾" or 1") – Use one per L-foot to secure rail to L-foot. Stainless steel. Supplied with L-foot in combination with flange nut, provides electrical bond between L-foot and rail.

❻**SERRATED FLANGE NUT** : Use one per L-foot to secure and bond rail to L-foot. Stainless steel. Supplied with L-foot.

❼**MODULE ENDCLAMP**: Pre-assembled universal clamp that secures module to rail at module flange by tightening 1/2" hex head bolt.

❽**MODULE MIDCLAMP**: Pre-assembled clamp provides module to module and module to rail bond. Aluminum clamp with stainless steel bonding pins and T-bolt. Available in clear or dark finish.

❾**MICROINVERTER MOUNTING BOLT**: Pre-assembled bolt, nut, and captive star washer attaches and bonds microinverter to rail.

**NOTE - POSITION INDICATOR: T-bolts have a slot in the hardware end corresponding to the direction of the T-Head.**

**NOTE - Pro Series Mid and End Clamps are single use only**

**NOTE - See GFT Installation Guide for installation of GFT EW BEAM SPLICE**

### Wrenches and Torque

| | Wrench or Socket Size | Recommended Torque (ft-lbs) |
|---|---|---|
| Mid Clamp ❽ | 1/2" | 11 |
| MLPE Mount ❾ | 1/2" | 10 |
| End Clamp ❼ | 1/2" | 5 |
| L-Foot to Rail ❻ | 1/2" | 30 |
| Rail Splice ❸ | 1/2" | 10 |

### Anti-Seize ❻❾

Stainless steel hardware can seize up, a process called galling. To significantly reduce its likelihood:
1. Apply minimal lubricant to bolts only where indicated in installation process, preferably Anti-Seize commonly found at auto parts stores (Anti-seize has been factory applied to mid clamp bolts)
2. Shade hardware prior to installation, and
3. Avoid spinning stainless nuts onto bolts at high speed.

## RAILS

| TYPE | PART NUMBER | DESCRIPTION |
|---|---|---|
| LIGHT RAIL | 315168M | SM LIGHT RAIL 168" MILL |
| | 315168D | SM LIGHT RAIL 168" DRK |
| | 315208M | SM LIGHT RAIL 208" MILL |
| | 315208D | SM LIGHT RAIL 208" DRK |
| | 315246M | SM LIGHT RAIL 246" MILL |
| | 315246D | SM LIGHT RAIL 246" DRK |
| STANDARD RAIL | 320132M | SM RAIL 132" MILL |
| | 310132C | SM RAIL 132" CLR |
| | 320168M | SM RAIL 168" MILL |
| | 310168C | SM RAIL 168" CLR |
| | 310168D | SM RAIL 168" DRK |
| | 320208M | SM RAIL 208" MILL |
| | 310208C | SM RAIL 208" CLR |
| | 320246M | SM RAIL 246" MILL |
| | 310246C | SM RAIL 246" CLR |
| | 310246D | SM RAIL 246" DRK |
| HEAVY DUTY RAIL | 410144M | SMHD, RAIL 144" MILL |
| | 410168M | SMHD, RAIL 168" MILL |
| | 410204M | SMHD RAIL 204" MILL |
| | 410246M | SMHD, RAIL 246" MILL |
| GFT EW BEAM | 411166M | GFT EW BEAM 166" MILL |
| | 411168M | GFT EW BEAM 168" MILL |
| | 411246M | GFT EW BEAM 246" MILL |

| SYMBOL | DESCRIPTION |
|---|---|
| AL | ALUMINUM |
| CLR | CLEAR ANODIZED |
| DRK | DARK BRONZE ANODIZED |
| SS | STAINLESS STEEL |
| DRK SS | BLACK OXIDE COATED STAINLESS STEEL |

| LETTER | SUPPORTED MODULE THICKNESS |
|---|---|
| B | 30MM -32MM |
| C | 33MM -36MM |
| D | 38MM -40MM |
| K | 39MM -41MM |
| F | 45MM -47MM |
| E | 50MM -51MM |

## MID CLAMPS AND END CLAMPS

| S.NO. | PART NUMBER | DESCRIPTION |
|---|---|---|
| 1 | 302021C | SM ENDCLAMP B CLR AL |
| 2 | 302021D | SM ENDCLAMP B DRK AL |
| 3 | 302022C | SM ENDCLAMP C CLR AL |
| 4 | 302022D | SM ENDCLAMP C DRK AL |
| 5 | 302023C | SM ENDCLAMP D CLR AL |
| 6 | 302023D | SM ENDCLAMP D DRK AL |
| 7 | 302024C | SM ENDCLAMP E CLR AL |
| 8 | 302024D | SM ENDCLAMP E DRK AL |
| 9 | 302025C | SM ENDCLAMP F CLR AL |
| 10 | 302025D | SM ENDCLAMP F DRK AL |
| 11 | 302026C | SM ENDCLAMP K CLR AL |
| 12 | 302026D | SM ENDCLAMP K DRK AL |
| 13 | 302027C | SM BND MIDCLAMP BC SS |
| 14 | 302027D | SM BND MIDCLAMP BC DRK SS |
| 15 | 302028C | SM BND MIDCLAMP EF SS |
| 16 | 302028D | SM BND MIDCLAMP EF DRK SS |
| 17 | 302029C | SM BND MIDCLAMP DK SS |

## MID CLAMPS AND END CLAMPS (CONT.)

| S.NO. | PART NUMBER | DESCRIPTION |
|---|---|---|
| 18 | 302029D | SM BND MIDCLAMP DK DRK SS |
| 19 | 302030D | SM MIDCLAMP PRO DRK |
| 20 | 302030M | SM MIDCLAMP PRO MILL |
| 21 | 302035M | SM ENDCLAMP PRO W/CAP |
| 22 | 302045D | UNIVERSAL AF MID CLAMP DRK |
| 23 | 302045M | UNIVERSAL AF MID CLAMP MILL |
| 24 | 302050D | UNIVERSAL AF END CLAMP DRK |
| 25 | 302050M | UNIVERSAL AF END CLAMP MILL |

## COMPONENTS

| S.NO. | PART NUMBER | DESCRIPTION |
|---|---|---|
| 1 | 303019M | BND SPLICE BAR PRO SERIES MILL |
| 2 | 303019D | BND SPLICE BAR PRO SERIES DRK |
| 3 | 304001C | L-FOOT SERR W/ T-BOLT, CLR |
| 4 | 304001D | L-FOOT SERR W/ T-BOLT, DRK |
| 5 | 009010S | SPLICE TEK SCRW #12-14X3/4" SS |
| 6 | 009020S | BND T-BOLT&NUT 3/8" X 3/4" SS |
| 7 | 009021S | BND T-BOLT&NUT 3/8" X 1" SS |
| 8 | 004055M | FLASHKIT PRO, MILL 10 PK |
| 9 | 004055D | FLASHKIT PRO, DRK 10 PK |
| 10 | 004015D | SOLARMOUNT FLASHKIT PRO SB, DARK |
| 11 | 004015M | SOLARMOUNT FLASHKIT PRO SB, MILL |
| 12 | 004085M | FLASHLOC COMP KIT MILL |
| 13 | 004085D | FLASHLOC COMP KIT DRK |
| 14 | 004275M | FLASHLOC DUO MILL |
| 15 | 004275D | FLASHLOC DUO DARK |
| 16 | 003250W | #12-14 X 2.50 SCREW HDW SS SD |

## COMPONENTS (CONT.)

| S.NO. | PART NUMBER | DESCRIPTION |
|---|---|---|
| 17 | 004CT5H | SOLARHOOK UNIV SIDE MT CT5 |
| 18 | 004CT1H | SOLARHOOK SPANISH 7" BASE |
| 19 | 004CT2H | SOLARHOOK SPANISH 9" BASE |
| 20 | 004FLAT | SOLARHOOK FLASHING FLAT |
| 21 | 004FLCT | SOLARHOOK FLASHING SPANISH FLCT |
| 22 | 004AT1H | SOLARHOOK FLAT TILE |
| 23 | 004ST1S | SOLARHOOK STONE COATED MT ST1 |
| 24 | 004AST1 | SOLARHOOK ADJ STONE COATED ST1 |
| 25 | 004300M | STANDOFF 3" 2 PIECE AL, MILL |
| 26 | 004300D | STANDOFF 3" 2 PIECE AL, DRK |
| 27 | 004400M | STANDOFF 4" 2 PIECE AL, MILL |
| 28 | 004400D | STANDOFF 4" 2 PIECE AL, DRK |
| 29 | 004600M | STANDOFF 6" 2 PIECE AL, MILL |
| 30 | 004600D | STANDOFF 6" 2 PIECE AL, DRK |
| 31 | 004700M | STANDOFF 7" 2 PIECE AL, MILL |
| 32 | 004700D | STANDOFF 7" 2 PIECE AL, DRK |
| 33 | 330007M | AL STNDOFF 3/8" BOLT&EPDMWSHR |
| 34 | 004013C | FLASH SOFT AL 18X18 OATEY 12836 |
| 35 | 008015S | WIRE BONDING CLIP W/ 8AWG |
| 36 | 309003P | SM/SM LIGHT RAIL END CAP |
| 37 | 004BUTYLM | SOLARMOUNT BUYTL ATT KIT #14s MILL |
| 38 | 004BUTYLD | SOLARMOUNT BUYTL ATT KIT #14s DARK |
| 39 | M40002 | GFT EW BEAM SPLICE |
| 40 | M31171 | 1/4" x 20 Self Drilling Screw (Buildex), ASTM A449/ SAE J429 (Similar Properties Confirmed by testing) |
| 41 | U-LUG | Grounding Lug Kit |

## MADE IN USA COMPONENTS LIST


| COMPONENT | DESCRIPTION | STANDARD PART NUMBER | MADE IN USA PART NUMBER |
|---|---|---|---|
| BUTYL ATTACHMENT KIT | SOLARMOUNT BUTYL ATT KIT #14S MILL | 004BUTYLM | 004BUTYLM-US |
| | SOLARMOUNT BUTYL ATT KIT #14S DARK | 004BUTYLD | 004BUTYLD-US |
| RAIL | SM LIGHT RAIL 168" DRK | 315168D | 315168D-US |
| | SM LIGHT RAIL 185" DRK | 315185D | 315185D-US |
| | SM LIGHT RAIL 246" DRK | 315246D | 315246D-US |
| | SM LIGHT RAIL 168" MILL | 315168M | 315168M-US |
| | SM LIGHT RAIL 185" MILL | 315185M | 315185M-US |
| | SM LIGHT RAIL 246" MILL | 315246M | 315246M-US |
| | SM RAIL 185" DRK | 310185D | 310185D-US |
| | SM RAIL 246" DRK | 310246D | 310246D-US |
| | SM RAIL 185" MILL | 320185M | 320185M-US |
| | SM RAIL 246" MILL | 320246M | 320246M-US |

**EXPANSION JOINT USED AS THERMAL BREAK**

Expansion joints prevent buckling of rails or system failure due to thermal expansion. Determine location of expansion joints prior to installation of L-feet and rails. To create a thermal expansion joint, set gap between rails that is sufficient for proper installation of end clamps and tooling to achieve required torque. A thermal break is required when a continuous length of spliced rails exceeds the length, in feet, shown in the table to the right. For additional concerns on thermal breaks in your specific project, please consult a licensed structural engineer.

Rails in expansion joint configurations are considered cantilevered and must follow the cantilever rule, on both sides of the expansion joint, which states that the maximum amount of rail that can be cantilevered is 1/3 the respective adjacent span. An expansion joint must not be spanned by a PV module. Installing a module over an expansion joint would defeat the goal of a thermal break and could result in damage to the array.

**Bonding connection for splice used as a thermal break. Option shown uses two Ilsco lugs (Model No. GBL-4DBT P/N GBL-4DBT - see product data sheet for more details) and solid copper wire. Optional grounding may be achieved through Enphase microinverter. See page 12.**




| | Maximum Continuous Length (ft.) of Spliced Rails | | | |
|---|---|---|---|---|
| | Solarmount Standard | | Solarmount Light | |
| | Attachment Span | | Attachment Span | |
| ΔT (°F) | 48" | 72" | 48" | 72" |
| 0-40 | 84 | 102 | 68 | 78 |
| 40-50 | 68 | 90 | 60 | 78 |
| 50-60 | 68 | 78 | 52 | 66 |
| 60-70 | 60 | 66 | 52 | 66 |
| 70-80 | 52 | 66 | 44 | 54 |
| 80-90 | 52 | 66 | 44 | 54 |
| 90-100 | 52 | 54 | 44 | 54 |
| 100-120 | 44 | 54 | 36 | 42 |
| 120-140 | 36 | 42 | 36 | 42 |

The values displayed are the maximum allowed rail length, in feet, without a thermal break.

These values apply only to the Flashkit Pro L-foot. For Flashloc Comp Mount or SM Butyl Mount or if your span is less than 48", refer to the Solarmount Design & Engineering Guide for max lengths of continuous rail before a thermal break is required.

The installer is responsible for determining the maximum temperature difference (ΔT) used to establish the maximum rail length, without expansion joint, at the install location.

As spans increase, so does the maximum reaction force that the rail exerts on the L-foot. It is the responsibility of the installer to ensure that Maximum Reaction Force does not exceed the shear capacity of the roof connection. See SM Design and Engineering Guide for corresponding reaction forces.

ΔT refers to the maximum difference in the temperature of the rail between installation and the extreme high or low temperature. The Extreme Annual Design Conditions table at the following url can be used as a reference when determining ΔT.

***http://ashrae-meteo.info/***

## PLANNING YOUR SOLARMOUNT INSTALLATIONS

The installation can be laid out with rails parallel to the rafters or perpendicular to the rafters. Note that SOLARMOUNT rails make excellent straight edges for doing layouts.

Center the installation area over the structural members as much as possible.

Leave enough room to safely move around the array during installation. Some building codes and fire codes require minimum clearances around such installations, and the installer should check local building code requirements for compliance.

The length of the installation area is equal to:


**Standard Series:**

- the total width of the modules,
- plus 1/4" inch for each space between modules (for mid- clamp),
- plus approximately 3" ( 1½ inches for each Endclamp)

**Pro Series:**

- the total width of the modules,
- plus 1" inch for each space between modules (for mid- clamp),
- plus 0 to 1" ( 0 to ½ inches for each Endclamp)

## RAILS MAY BE PLACED PARALLEL OR PERPENDICULAR TO RAFTERS




## LAYING OUT L-FEET FOR TOP CLAMPS

L-feet, in conjunction with proper flashing equipment and techniques, can be used for attachment through existing roofing material, such as asphalt shingles, sheathing or sheet metal to the building structure.


Locate and mark the position of the L-feet lag screw holes within the installation area as shown below. Follow manufacturer module installation guide for rail spacing based on appropriate mounting locations

**NOTE: For expansion joint requirements, refer to page 5. Rail Lengths and locations of l-feet for expansion joints will need to be determined at this stage in planning system layout.**


If multiple rows are to be installed adjacent to one another, it is not likely that each row will be centered above the rafters. Adjust as needed, following the guidelines below as closely as possible.

**Refer to Unirac Solarmount D&E Guide & U-Builder for allowable spans and cantilevers.**


## LAYOUT WITH RAILS PERPENDICULAR TO RAFTERS (RECOMMENDED)




Note: Modules should be positioned so that rails are flush with edge of module or extending no more than 1/2" beyond edge of module. The modules should not extend past (overhang) the ends of rails.




**ROOF PREPARATION**: Layout and install flashing at rafter locations determined per Design and Engineering Guide.




**DRILL PILOT HOLES**: Center the roof attachment over the rafter and drill a pilot hole(s) for the lag bolt(s).

**NOTE: Determine lag bolt size and embedment depth.**

**Quick Tip: Pre-drill the pilot hole through the flat flashing lag bolt location for easier installation.**





**FLASHING INSTALLATION**: Insert the flashing so the top part is under the next row of shingles and the hole lines up with the pilot hole.



**INSTALL LAG BOLTS & L-FOOT**: Insert the lag bolt through the L-Foot in the order shown in the illustration. Verify proper orientation before tightening lag bolts.

**For high snow load conditions, install the L-foot as shown above, and install the rail on the downslope face of the L-Foot**








**2 PIECE ALUMINUM STANDOFF WITH FLASHING & L-FOOT:**

- If necessary cut an opening in the roofing material over a rafter to accommodate the flashing riser.
- Install the standoff, ensuring that both lag bolts are screwed into the rafter.
- Insert the flashing under the shingle above and over the shaft of the standoff. (No-Calk™ collar does not require sealing of the flashing and standoff shaft)
- Add L-Foot to top with bolt that secures the EPDM washer to the top of the standoff.

**See Standoffs Installation Manual for Additional Details.**







**Side MOUNT SOLARHOOK:**


- Remove or slide up the roof tile, position the roof hook above the roof rafter
- Place SolarHook in the middle of the underlying interlocking tile's valley. Drill 3/16 inch pilot holes through the underlayment into the center of the rafters. Securely fasten each tile hook to the rafters using included lag screws.
- Slide down or re-insert the tile.


See Unirac Solarhook Installation Manual for Additional Information.

**SPLICE INSTALLATION (IF REQUIRED PER SYSTEM DESIGN)**
If your installation uses SOLARMOUNT splice bars, attach the rails together before mounting to the L-feet/footings. Use splice bars only with flush installation and those that use low-profile tilt legs. A rail must be supported by more than one footing on both sides of the splice. There can be a gap between rails, up to 3/16" at the splice connections. To install, slide T-feature on splice into the T-slot on each rail, centering the splice between the two rails. Tighten each bolt until the bolt-head is flush against the splice and torqued to 10 ft-lbs. Installation is complete when the bonding hardware penetrates the opposite side of the rail and the assembly torque is achieved. T-bolts should not be placed less than a distance of 1" from the end of the rail regardless of a splice.


**TORQUE VALUE**
**Hex head socket size ½" – Do not exceed 10 ft-lbs. Do not use Anti-Seize. See table on page 5 for max length of spliced rails. An expansion joint is required above the lengths published in the table.**

Rails in splice joint configurations are considered cantilevered and must follow the cantilever rule, on both sides of the splice, which states that the maximum amount of rail that can be cantilevered is 1/3 the respective adjacent span. See table on page 5.







**PLACE T-BOLT INTO RAIL & SECURE BOLT**: Insert 3/8" T-bolt into rail at L-foot locations. Apply Anti-Seize to bolt. Rotate T-bolt into position.




**SECURE T-BOLT**: Apply Anti-Seize to bolt. Rotate T-bolt into position.





**ALIGN POSITION INDICATOR**: Hand tighten nut until rail alignment is complete. Verify that position indicator on bolt is vertical (perpendicular to rail)


**TORQUE VALUE: 3/8" nut to 30 ft-lbs**

**ALIGN RAILS**: Align one pair of rail ends to the edge of the installation area. The opposite pair of rail ends will overhang installation area. Do not Trim them off until the installation is complete. If the rails are perpendicular to the rafters, either end of the rails can be aligned, but the first module must be installed at the aligned end.


If the rails are parallel to the rafters, the aligned end of the rails must face the lower edge of the roof. Securely tighten all hardware after alignment is complete.

Mount modules to the rails as soon as possible. Large temperature changes may bow the rails within a few hours if module placement is delayed.







**INSTALL MICROINVERTER MOUNT T-BOLT**: Apply Anti-Seize and install pre-assembled ¼" dia. bonding T-bolts into top ¼" rail slot at microinverter locations. Rotate bolts into position.





**INSTALL MICROINVERTER**: Install microinverter on to rail. Engage with bolt.





**INSTALL MICROINVERTER:**

**TORQUE VALUE**
**1/4" nut to 10 ft-lbs with Anti-Seize.**




**ALIGN POSITION INDICATOR**: Verify that position indicator on bolt is perpendicular to rail.



**SM EQUIPMENT GROUNDING THROUGH ENPHASE MICROINVERTERS**

The Enphase M215 and M250 microinverters have integrated grounding capabilities built in. In this case, the DC circuit is isolated from the AC circuit, and the AC equipment grounding conductor (EGC) is built into the Enphase Engage integrated grounding (IG) cabling.


In order to ground the SOLARMOUNT racking system through the Enphase microinverter and Engage cable assembly, there must be a minimum of three PV modules connected to the same trunk cable within a continuous row. Continuous row is defined as a grouping of modules installed and bonded per the requirements of this installation guide sharing the same two rails. The microinverters are bonded to the SOLARMOUNT rail via the mounting hardware. Complete equipment grounding is achieved through the Enphase Engage cabling with integrated grounding (IG). No additional EGC grounding cables are required, as all fault current is carried to ground through the Engage cable.


**SOLARMOUNT INTEGRATED BONDING ADVANTAGE**

WITH SYSTEM GROUNDING THROUGH ENPHASE MICROINVERTERS AND TRUNK CABLES

**LOSE ALL THE COPPER & LUGS**


| CONTINUOUS RAIL & ELECTRICAL BONDING SPLICE |
|---|
| **Enphase Microinverter (MI) Requirements (Model No. M215 & M250)** |
| 3 Microinverters sharing same trunk cable & rails |




ELECTRICAL BONDING SPLICE


| EXPANSION JOINT W/GROUNDING LUGS & COPPER JUMPER |
|---|
| **Enphase Microinverter (MI) Requirements (Model No. M215 & M250)** |
| 3 or more Microinverters sharing same trunk cable & rails |




EXPANSION JOINT USED AS THERMAL BREAK W/ GROUNDING LUGS & COPPER JUMPER


| EXPANSION JOINT W/O ELECTRICAL BONDING CONNECTION |
|---|
| **Enphase Microinverter (MI) Requirements (Model No. M215 & M250)** |
| MIn. 3 Microinverters on each side of thermal break |



EXPANSION JOINT USED AS THERMAL BREAK W/O ELECTRICAL BONDING CONNECTION

NOTE:
THE ABOVE IMAGES ARE SAMPLE CONFIGURATIONS TO ILLUSTRATE THE REQUIREMENTS FOR SM SYSTEM GROUNDING THROUGH ENPHASE MICROINVERTERS DESCRIBED ON page 11.






**GROUNDING LUG MOUNTING DETAILS:**
Details are provided for the Ground lug, WEEB and Ilsco products. The WEEBLug has a grounding symbol located on the lug assembly. The Ilsco lug has a green colored set screw for grounding indication purposes. The Ground lug is pre-assembled lug compatible with 0.25 inch T-Bolt slot rails .Installation must be in accordance with NFPA NEC 70, however the electrical designer of record should refer to the latest revision of NEC for actual grounding conductor cable size.

**Required if not using approved integrated grounding microinveters**

| GROUNDING LUG - BOLT SIZE & DRILL SIZE | | | |
|---|---|---|---|
| **GROUND LUG** | **Unirac P/N** | **BOLT SIZE** | **DRILL SIZE** |
| Grounding Lug | U-LUG | 1/4" | N/A - Place in Top SM Rail Slot |
| WEEB Lug | 008002S | 1/4" | N/A - Place in Top SM Rail Slot |
| ILSCO Lug | 008009P | #10-32 | 7/32" |

- Torque value for Grounding Lug is 10 ft-lbs.
- Torque value for WEEB and ILSCO Lugs varies depending on conductor size. See product data sheet for torque values.









**WEEBLUG CONDUCTOR - UNIRAC P/N 008002S:**
Apply Anti Seize and insert a bolt in the aluminum rail and through the clearance hole in the stainless steel flat washer. Place the stainless steel flat washer on the bolt, oriented so the dimples will contact the aluminum rail. Place the lug portion on the bolt and stainless steel flat washer. Install stainless steel flat washer, lock washer and nut. Tighten the nut until the dimples are completely embedded into the rail and lug.

**TORQUE VALUE 10 ft lbs.**

**See product data sheet for more details, Model No. WEEB-LUG-6.7**





**ILSCO LAY-IN LUG CONDUCTOR - UNIRAC P/N 008009P**: Alternate Grounding Lug - Drill, deburr hole and bolt thru both rail walls per table.


**TORQUE VALUE 5 ft lbs.**

**See ILSCO product data sheet for more details, Model No. GBL-4DBT.**

**NOTE: ISOLATE COPPER FROM ALUMINUM CONTACT TO PREVENT CORROSION**

## GROUNDING LUG (P/N: U-LUG) INSTALLATION STEPS:







*GROUNDING LUG CLIP TABS INSIDE THE RAIL*

*GROUNDING LUG CLIP TABS OUTSIDE THE RAIL*


### STEP 1: POSITION THE GROUNDING LUG

- Place the Grounding Lug on the rail with pre-assembled 1/4" T-bolt and nut.
- Ensure the Grounding Lug Clip tabs are positioned inside the rail.



### STEP 2: INSERT GROUNDING WIRE


- Insert the copper grounding wire (6-12 AWG) into the Grounding Lug Clip.



### STEP 3: SECURE GROUNDING LUG TO RAIL

- Tighten the 1/4" nut to secure the Grounding Lug to Rail.


**Torque the 1/4" nut to 10 ft-lbs.**



### ALIGN POSITION INDICATOR

- Verify that the position indicator on the bolt is perpendicular to the rail.


**NOTE: 1.Follow the above instructions when attaching the Grounding Lug to the SM Light Rail.**
**2.The Grounding Lug is single use only.**




**TO ESTABLISH EAST-WEST BONDING**

- Place a Grounding Lug at one end of the rail, closer to the adjacent rail end
- Insert the grounding wire into the Ground Lug and tighten the 1/4" nut to secure both the Grounding Lug and the wire to the rail


**Torque the 1/4" nut to 10 ft-lbs.**




**INSTALL MODULE END CLAMPS**: The End clamp is supplied as an assembly with a 1/2" hex head bolt that is accessible at the ends of rails. The clamp should be installed on the rails prior to installing end modules.





**INSTALL END CLAMPS ON RAIL**: Slide end clamp on to rail by engaging the two t-guide brackets with the top slot of the rails. **Ensure bolt is extended as far as possible so that clamp is positioned at max. distance from end of rail.**






**POSITION END CLAMPS**: Slide end clamp assembly on to rail until bolt head engages with end of rail **End clamps are positioned on rails prior to the first end module and prior to the last end module.**




**NOTE: To assist insertion of clamp into rail slot, Pressure may be applied to top or side of bracket as shown. Do not force clamp into rail by pushing on bolt with excessive force.**









**INSTALL FIRST MODULE**: Install the first end module onto rails with the flange of the module frame positioned between end clamps an ends of rails.


**ENGAGE CLAMP**: While holding module in position and with flange in full contact with rail, rotate end clamp bolt until clamp engages with flange to provide clamp force.
**To ensure bolt is not over-torqued, use low torque setting on drill or If using an impact driver, stop rotation as soon as impact action of driver begins.**
**TORQUE VALUE**
**End clamp bolt to 5 ft-lbs, No anti-seize**





For best appearance, position module flush with ends of rails. Rails should not extend more than 1/2" beyond module. Module must be fully supported by rails and cannot overhang ends of rails.




**INSTALL MIDCLAMPS**: Midclamp is supplied as an assembly with a T-bolt for module installation. Clamp assemblies may be positioned in rail near point of use prior to module placement.




**INSERT MIDCLAMP ASSEMBLY**: Insert 1/4" T-Bolt into top slot of rail





**MIDCLAMP**: Rotate midclamp assembly and slide until clamp is against module frame. Do not tighten nut until next module is in position. Ensure bolt is perpendicular to rail.




**PLACE ADJACENT MODULE AGAINST CLAMPS:** Modules must be tight against clamps with no gaps. Tighten nut to required torque.


**TORQUE VALUE: 11 ft-lbs. No anti-seize.**



**POSITION INDICATOR - SERRATED T-BOLT:** Verify the T-bolt position indicator is perpendicular to the rail.





**INSTALL REMAINING MID-CLAMPS**: Proceed with module installation. Engage each module with previously positioned Midclamp assemblies.



**POSITION T-BOLT ALIGNMENT MARKS:** Verify that the position indicator(s) & T-bolt shaft(s) are angled in the correct position. Tighten to final torque.


**TORQUE VALUE: 11 ft-lbs. No anti-seize.**




**FINISH MODULE INSTALLATION**: Proceed with module installation. Engage each module with the previously positioned clamp assembly:

# BONDING CONNECTION GROUND PATHS







## BONDING MIDCLAMP ASSEMBLY

## BONDING MIDCLAMP ASSEMBLY


1. Aluminum mid clamp with stainless steel bonding pins that pierce module frame anodization to bond module to module through clamp
2. Stainless steel nut bonds aluminum clamp to stainless steel T-bolt
3. Serrated T-bolt head penetrates rail anodization to bond T-bolt, nut, clamp, and modules to SM rail




## BONDING RAIL SPLICE BAR


1. Bonding Hardware creates bond between splice bar and each rail section
2. Aluminum splice bar spans across rail gap to create rail to rail bond. Rail on at least one side of splice will be grounded.


Note: Splice bar and bolted connection are non-structural. The splice bar function is rail alignment and bonding.




## RAIL TO L-FOOT w/BONDING T-BOLT


1. Serrated flange nut removes L-foot anodization to bond L-Foot to stainless steel T-bolt
2. Serrated T-bolt head penetrates rail anodization to bond T-bolt, nut, and L-foot to grounded SM rail





## BONDING MICROINVERTER MOUNT


1. Hex nut with captive lock washer bonds metal microinverter flange to stainless steel T-bolt
2. Serrated T-bolt head penetrates rail anodization to bond T-bolt, nut, and L-foot to grounded SM rail System ground including racking and modules may be achieved through the trunk cable of approved microinverter systems. See page 12 for details




## RACK SYSTEM GROUND

1. WEEB washer dimples pierce anodized rail to create bond between rail and lug
2. Solid copper wire connected to lug is routed to provide final system ground connection.
NOTE: Ilsco lug can also be used when secured to the side of the rail. See page 13 for details




**TEMPORARY BONDING CONNECTION DURING ARRAY MAINTENANCE**
When removing modules for replacement or system maintenance, any module left in place that is secured with a bonding Midclamp will be properly grounded. If a module adjacent to the end module of a row is removed or if any other maintenance condition leaves a module without a bonding mid clamp, a temporary bonding connection must be installed as shown

- Attach Ilsco SGB4 to wall of rail
- Attach Ilsco SGB4 to module frame
- Install solid copper wire jumper to Ilsco lugs

**ELECTRICAL CONSIDERATIONS**
SOLARMOUNT is intended to be used with PV modules that have a system voltage less than or equal to that allowable by NEC. For standard system grounding a minimum 10AWG, 105°C copper grounding conductor should be used to ground a system, according to the National Electric Code (NEC). It is the installer's responsibility to check local codes, which may vary. See below for interconnection information.


**INTERCONNECTION INFORMATION**
There is no size limit on how many SOLARMOUNT & PV modules can be mechanically interconnected for any given configuration, provided that the installation meets the requirements of applicable building and fire codes.

**GROUNDING NOTES**
The installation must be conducted in accordance with the National Electric Code (NEC) and the authority having jurisdiction. Please refer to these resources in your location for required grounding lug quantities specific to your project.

The grounding / bonding components may overhang parts of the array so care must be made when walking around the array to avoid damage.


Conductor fastener torque values depend on conductor size. See product data sheets for correct torque values.

**PERIODIC INSPECTION**: Conduct periodic inspections for loose components, loose fasteners or any corrosion, immediately replace any affected components.




**TRIM MIDCLAMPS**: Ensure Trim lip is in contact with module face and verify alignment marks on T-bolts are in proper position, tighten midclamp on Trim, repeat at each gap between modules.


**TORQUE VALUE: 11 ft-lbs. No anti-seize.**



**FINISH TRIM INSTALLATION. CUT EXCESS TRIM AND INSTALL TRIM CLIPS:**
Attach trim to modules with at least one trim clip at each end of array and at locations where additional support is needed. Each section of trim must be attached to modules with at least one mid clamp.




**INSTALL END CAPS**: End caps install as supplied on SM standard rail and SM light rail. If desired for SM light rail, the end cap may be modified as shown by hand, or by using a cutting tool.




**❶RAIL**: Supports PV modules. Use at least two per row of modules. Aluminum extrusion, available in mill, clear anodized, or dark anodized.

**❷❸RAIL SPLICE**: Non structural splice joins, aligns, and electrically bonds rail sections into single length of rail. Forms a rigid splice joint, 4 inches long, preassembled with bonding hardware. Available in dark anodized or mill finish.

**❹L-FOOT**: Use to secure rails through roofing material to building structure. Refer to loading tables or U-Builder for spacing.

**❺ L-FOOT T- BOLT**: (3/8" x ¾" or 1") – Use one per L-foot to secure rail to L-foot. Stainless steel. Supplied with L-foot in combination with flange nut, provides electrical bond between L-foot and rail.

**❻SERRATED FLANGE NUT** : Use one per L-foot to secure and bond rail to Lfoot. Stainless steel. Supplied with L-foot.

**❼MODULE ENDCLAMP**: Provides bond from rail to endclamp. Pre-assembled aluminum clamp available in clear or dark finish. Supplied washer keeps clamp and bolt upright for ease of assembly.

**❽MODULE MIDCLAMP**: Pre-assembled clamp provides module to module and module to rail bond. Stainless steel clamp and T-bolt. Available in clear or dark finish.

**❾MICROINVERTER MOUNTING BOLT**: Pre-assembled bolt and nut attaches and bonds microinverter to rail. Washer at base keeps bolt upright for ease of assembly.

**NOTE - POSITION INDICATOR**: T-bolts have a slot in the hardware end corresponding to the direction of the T-Head.

**NOTE - Standard Series Mid and End Clamps are single use.**

## Wrenches and Torque

| | Wrench Size | Recommended Torque (ft-lbs) |
|---|---|---|
| 1/4" Hardware ❼❽❾ | 7/16" | *10 |
| 3/8" Hardware ❺ | 9/16" | *30 |
| #12 Hardware ❸ | 5/16" | 10 |

Torques are not designed for use with wood connectors
*w/Anti-Seize.

## Anti-Seize*

Stainless steel hardware can seize up, a process called galling. To significantly reduce its likelihood:
1. Apply minimal lubricant to bolts, preferably Anti-Seize commonly found at auto parts stores
2. Shade hardware prior to installation, and
3. Avoid spinning stainless nuts onto bolts at high speed.

**B SIZE**
ENDCLAMP

Module Thickness
30mm to 32mm
1.18in to 1.26in

**C SIZE**
ENDCLAMP

Module Thickness
33mm to 36mm
1.30in to 1.42in

**D SIZE**
ENDCLAMP

Module Thickness
38mm to 40mm
1.50in to 1.57in

**K SIZE**
ENDCLAMP


Module Thickness
39mm to 41mm
1.54in to 1.61in

**F SIZE**
ENDCLAMP


Module Thickness
45mm to 47mm
1.77in to 1.85in

**E SIZE**
ENDCLAMP


Module Thickness
50mm to 51mm
1.97in to 2.00in




**BC SIZE**
MIDCLAMP
2in Long T-bolt




**DK SIZE**
MIDCLAMP
2.25in Long T-bolt




**EF SIZE**
MIDCLAMP
2.5in Long T-bolt




**PLACE T-BOLT INTO RAIL & SECURE BOLT**: Insert 3/8" T-bolt into rail at L-foot locations. Apply Anti-Seize to bolt. Rotate T-bolt into position.




**SECURE T-BOLT**: Apply Anti-Seize to bolt. Rotate T-bolt into position.





**ALIGN POSITION INDICATOR**: Hand tighten nut until rail alignment is complete. Verify that position indicator on bolt is vertical (perpendicular to rail)

**TORQUE VALUE: 3/8" nut to 30 ft-lbs**

**ALIGN RAILS**: Align one pair of rail ends to the edge of the installation area. The opposite pair of rail ends will overhang installation area. Do not Trim them off until the installation is complete. If the rails are perpendicular to the rafters, either end of the rails can be aligned, but the first module must be installed at the aligned end.

If the rails are parallel to the rafters, the aligned end of the rails must face the lower edge of the roof. Securely tighten all hardware after alignment is complete.


Mount modules to the rails as soon as possible. Large temperature changes may bow the rails within a few hours if module placement is delayed.




# ENDCLAMP & FIRST MODULE

## INSTALLATION GUIDE






**INSTALL MODULE ENDCLAMPS**: The Endclamp is supplied as an assembly with a T-bolt, serrated flange nut, and washer. The washer retains the clamp at the top of the assembly. This will enable the clamp to remain upright for module installation.




**INSERT ENDCLAMP T-BOLT**: Insert 1/4" T-bolt into rail.




**ROTATE ENDCLAMP T-BOLT**: Rotate T-bolt into position. Verify that the position indicator & T-bolt shaft are angled in the correct position.

**End clamps are positioned on rails prior to the first end module and installed after the last end module.**





**INSTALL FIRST MODULE**: Install the first end module onto rails. Engage module frame with Endclamps. Verify that the position indicator & T-bolt shaft are angled in the correct position.


**TORQUE VALUE: 1/4" nuts to 10 ft-lbs. with Anti Seize**




**POSITION INDICATOR - SERRATED T-BOLT**: Verify the T-bolt position indicator is perpendicular to the rail.




**POSITION INDICATOR - NON-SERRATED T-BOLT**: Verify the T-bolt position indicator is angled as shown. **FOR USE WITH MILL FINISH RAIL ONLY.**




**INSTALL MIDCLAMPS**: Midclamp is supplied as an assembly with a T-bolt for module installation. Clamp assemblies may be positioned in rail near point of use prior to module placement.




**INSERT MIDCLAMP T-BOLT**: Apply Anti-Seize and insert 1/4" T-bolt into rail.





**ROTATE MIDCLAMP T-BOLT**: Rotate bolt into position and slide until bolt and clamp are against module frame. Do not tighten nut until next module is in position. Verify that the position indicator & T-bolt shaft are angled in the correct position.




**POSITION INDICATOR - SERRATED T-BOLT**: Verify the T-bolt position indicator is perpendicular to the rail.

## TRIM INSTALLATION INSTRUCTIONS




**TRIM MIDCLAMPS**: Ensure Trim lip is in contact with module face and verify alignment marks on T-bolts are in proper position, tighten midclamp on Trim, repeat at each gap between modules.

**TORQUE VALUE: 1/4" nuts to 10 ft-lbs with Anti Seize**





**INSTALL REMAINING MID-CLAMPS**: Proceed with module installation. Engage each module with previously positioned Midclamp assemblies.


**NOTE: Apply Anti-Seize to each Mid Clamp prior to installation.**



**POSITION T-BOLT ALIGNMENT MARKS**:
**Verify that the position indicator(s) & T-bolt shaft(s) are angled in the correct position.**


**TORQUE VALUE: 1/4" nuts to 10 ft-lbs. with Anti Seize**






**INSTALL ENDCLAMPS**: Apply Anti-Seize and install final Endclamps in same manner as first Endclamps. Slide clamps against module.

**TORQUE VALUE: 1/4" nuts to 10 ft-lbs. with Anti Seize.**





**POSITION T-BOLT ALIGNMENT MARKS & CUT RAIL**: Verify that the position indicator(s) & T-bolt shaft(s) are angled in the correct position. Trim off any excess rail, being careful not to cut into the roof. Allow ½" between the Endclamp and the end of the rail.

**FINISH MODULE INSTALLATION**: Proceed with module installation. Engage each module with the previously positioned clamp assembly:


- Install second module
- Install remaining Midclamps & modules & position alignment marks
- Install Endclamps & position alignment marks
- Cut rail to desired length

## TRIM INSTALLATION INSTRUCTIONS




**FINISH TRIM INSTALLATION, INSTALL ENDCLAMP & CUT EXCESS RAIL**: Install final endclamp & Cut away excess Trim at end of array or where required for proper cantilevers. **See D&E Guide or U-Builder for allowable cantilevers.**

**TORQUE VALUE**
**1/4" nuts to 10 ft-lbs with Anti Seize**




**PREPARATION**: At front edge of array, ensure at least 3.25 inches of space between modules and roof surface and that modules are aligned to within 3/8". Plan for Trim length so that Endclamps can be properly installed.




**1ST MIDCLAMP**: Position Trim in front of array. Insert Midclamp into the Trim slot, aligned with the gap between the 1st two modules at either end of array.

**NOTE: Apply Anti-Seize to Each Mid-Clamp prior to installation**




**MOUNT TRIM**: Position Trim beneath modules by sliding T-bolt into gap between modules and tighten. Midclamp should stay in position and support Trim. Tighten snugly enough so that Trim is held firmly in place.


**TORQUE VALUE: Do not exceed specified torque value (10 ft-lbs)**



**CLEAR T-BOLT SLOT**: Rotate unattached end of Trim out and away from array so T-bolt slot (at next T-bolt insertion point) is clear of modules. This may require force to deflect the Trim slightly. Deflect only enough to insert T-bolt.




**INSERT MIDCLAMPS**: Insert T-bolt into slot and slide clamp (rotating Trim) into position between modules and leave loose. Continue to work down array, inserting Midclamps and positioning in gaps between modules.




**FASTEN MIDCLAMPS**: Return to each inserted Midclamp. Ensuring Trim lip is in contact with module face and verifying alignment marks on T-bolts are in proper position, tighten clamp.

**TORQUE VALUE**
**1/4" nuts to 10 ft-lbs w/ Anti Seize**




**ENDCLAMPS**: Install Endclamps per previous Endclamp install instructions

**TORQUE VALUE**
**1/4" nuts to 10 ft-lbs w/ Anti Seize**




**CUT EXCESS TRIM**: Mark excess Trim and cut at end of array or where required for proper cantilevers.

# BONDING CONNECTION GROUND PATHS




## BONDING MIDCLAMP ASSEMBLY


1. Stainless steel Midclamp points, 2 per module, pierce module frame anodization to bond module to module through clamp.
2. Serrated flange nut bonds stainless steel clamp to stainless steel T-bolt
3. Serrated T-bolt head penetrates rail anodization to bond T-bolt, nut, clamp, and modules to grounded SM rail.




## ENDCLAMP ASSEMBLY

1. Serrated flange nut bonds aluminum Endclamp to stainless steel T-bolt
2. Serrated T-bolt head penetrates rail anodization to bond T-bolt, nut, and Endclamp to grounded SM rail


**Note: End clamp does not bond to module frame.**




## BONDING RAIL SPLICE BAR


1. Bonding Hardware creates bond between splice bar and each rail section
2. Aluminum splice bar spans across rail gap to create rail to rail bond. Rail on at least one side of splice will be grounded.


**Note: Splice bar and bolted connection are non-structural. The splice bar function is rail alignment and bonding.**




## RAIL TO L-FOOT w/BONDING T-BOLT


1. Serrated flange nut removes L-foot anodization to bond L-Foot to stainless steel T-bolt
2. Serrated T-bolt head penetrates rail anodization to bond T-bolt, nut, and L-foot to grounded SM rail




## BONDING MICROINVERTER MOUNT


1. Hex nut with captive lock washer bonds metal microinverter flange to stainless steel T-bolt
2. Serrated T-bolt head penetrates rail anodization to bond T-bolt, nut, and L-foot to grounded SM rail System ground including racking and modules may be achieved through the trunk cable of approved microinverter systems. See page 12 for details





## RACK SYSTEM GROUND

1. WEEB washer dimples pierce anodized rail to create bond between rail and lug
2. Solid copper wire connected to lug is routed to provide final system ground connection.

**NOTE: Ilsco lug can also be used when secured to the side of the rail.** **See page 12 for details**




**TEMPORARY BONDING CONNECTION DURING ARRAY MAINTENANCE**

When removing modules for replacement or system maintenance, any module left in place that is secured with a bonding Midclamp will be properly grounded. If a module adjacent to the end module of a row is removed or if any other maintenance condition leaves a module without a bonding mid clamp, a temporary bonding connection must be installed as shown

- Attach Ilsco SGB4 to wall of rail
- Attach Ilsco SGB4 to module frame
- Install solid copper wire jumper to Ilsco lugs

**ELECTRICAL CONSIDERATIONS**

SOLARMOUNT is intended to be used with PV modules that have a system voltage less than or equal to that allowable by the NEC. For standard system grounding a minimum 10AWG, 105°C copper grounding conductor should be used to ground a 1000 VDC system, according to the National Electric Code (NEC). It is the installer's responsibility to check local codes, which may vary. See below for interconnection information.

**INTERCONNECTION INFORMATION**

There is no size limit on how many SOLARMOUNT & PV modules can be mechanically interconnected for any given configuration, provided that the installation meets the requirements of applicable building and fire codes.

**GROUNDING NOTES**

The installation must be conducted in accordance with the National Electric Code (NEC) and the authority having jurisdiction. Please refer to these resources in your location for required grounding lug quantities specific to your project.


The grounding / bonding components may overhang parts of the array so care must be made when walking around the array to avoid damage.


Conductor fastener torque values depend on conductor size. See product data sheets for correct torque values.

**UL2703 CERTIFICATION MARKING LABEL**


Unirac SOLARMOUNT is listed to UL 2703. Certification marking is embossed on all mid clamps as shown. Labels with additional information will be provided . After the racking system is fully assembled, a single label should be applied to the SOLARMOUNT rail at the edge of the array. Before applying the label, the corners of the label that do not pertain to the system being installed must be removed so that only the installed system type is showing.

**Note: The sticker label should be placed such that it is visible, but not outward facing.**




SM STANDARD RAIL




SM LIGHT RAIL

The SOLARMOUNT system has been certified and listed to the UL 2703 standard (Rack Mounting Systems and Clamping Devices for Flat-Plate Photovoltaic Modules and Panels). This standard included electrical grounding, electrical bonding, mechanical load and fire resistance testing.

In conducting these tests, specific modules are selected for their physical properties so that the certifications can be broadly applied. The following lists the specific modules that were tested and the applicability of those certifications to other modules that might come onto the market. PV modules may have a reduced mechanical load rating, independent of the SM load rating. Please consult the PV module manufacturer's installation guide for more information.

In addition to UL 2703 certification, Unirac performs internal testing beyond the requirements of certification tests in order to establish system functional limits, allowable loads, and factors of safety. These tests include functional system tests, and destructive load testing.

**MECHANICAL LOAD TEST MODULES**

The modules selected for UL 2703 mechanical load testing were selected to represent the broadest range possible for modules on the market. The tests performed cover the following basic module parameters:
Frame thicknesses greater than or equal to 1.0 mm
Basic single and double wall frame profiles (some complex frame profiles could require further analysis to determine applicability)
Clear and dark anodized aluminum frames`

| Tested Modules | | | |
|---|---|---|---|
| **Module Manufacturer** | **Model/Series** | **Area [sqft]** | **UL2703 Certification Load Ratings** |
| Hyundai | HiS-S325TI | 21.06 | Down– 113 PSF, Up – 50 PSF<br>Down-Slope – 15 PSF |
| SunPower | SPR-P19-395-COM | 22.20 | Down– 113 PSF, Up – 50 PSF<br>Down-Slope – 15 PSF |
| First Solar | FS-6xxx-P | 27.12 | Down– 33.9 PSF, Up – 33.9 PSF<br>Down-Slope – 16.5 PSF |
| Q Cells | Q Peak Duo XL-G11.3/BFG | 29.49 | Down: 31.18 PSF, Up: 31.18 PSF,<br>Down-Slope: 9.8 PSF |
| Trina | TSM-DEG21C.20 | 33.43 | Down: 27.79 PSF, Up: 28.05 PSF,<br>Down-Slope: 9.8 PSF |

**SYSTEM LEVEL FIRE CLASSIFICATION**

The system fire class rating requires installation in the manner specified in the SOLARMOUNT Installation Guide. SOLARMOUNT has been classified to the system level fire portion of UL2703. SOLARMOUNT has achieved system level performance for steep sloped roofs and low sloped roofs. See table below for definition of steep sloped and low sloped roofs. The system is to be mounted over fire resistant roof covering rated for the application. There is no required minimum or maximum height limitation above the roof deck to maintain the system fire rating for SOLARMOUNT. Module Types, System Level Fire Ratings, & Mitigation Requirements are listed below:

| ROOF TYPE | Rail Type | Module Fire Type | System Level Fire Rating | Rail Direction | Module Orientation | Mitigation Required |
|---|---|---|---|---|---|---|
| Steep Slope - roof pitches ≥ 2 in/ft | Standard & HD Rail | 1, 2, 3 with metal frame, 10 with metal frame, 19, 22, 25, 29, 30 & 38 | Class A | Parallel OR Perpendicular to Ridge | Landscape OR Portrait | None Required |
| | Light Rail | 1, 2, 29, 30 & 38 | | | | None Required |
| | Standard, Light, & HD Rail | 4 & 5 | | | | Trim installation per Solar Mount Installation Guide |
| Low Slope - roof pitches < 2in/ft | Standard, Light, & HD Rail | Type 1, 2, 29, 30 & 38 | Class A | Parallel OR Perpendicular to Ridge | Landscape OR Portrait | None Required |

**This racking system may be used to ground and/or mount a PV module complying with UL1703 or UL61730 only when the specific module has been evaluated for grounding and/or mounting in compliance with the included instructions.**

## Electrical Bonding and Grounding Test Modules

The list below is not exhaustive of compliant modules but shows those that have been evaluated and found to be electrically compatible with the SOLARMOUNT system.

| Manufacture | Module Model / Series |
|---|---|
| Aionrise | AION60G1, AION72G1 |
| Aleo | P-Series & S-Series |
| AMPS | AMPS-xxxN-108BB<br>AMPS-xxxP-54BB |
| Aptos Solar | DNA-108-(MF/BF)10-xxxW<br>DNA-120-(MF/BF)10-xxxW<br>DNA-120-(MF/BF)23<br>DNA-120-(MF/BF)26<br>DNA-120-MF10<br>DNA-144-(MF/BF)23<br>DNA-144-(MF/BF)26<br>DNA-144-BF10-xxxW-DG |
| Astronergy | ASM6612P Series<br>CHSM6612 M, M/HV<br>CHSM6612P/HV Series<br>CHSM6612P Series<br>CHSM66M(DG)/F-BH (fire type 29 only)<br>CHSM72M(DG)/F-BH<br>CHSM72M-HC<br>CHSM72N(DG)/F-BH |
| Auxin | AXN10Mxxx<br>AXN6M610T<br>AXN6M612T<br>AXN6P610T<br>AXN6P612T<br>AXNG1M SERIES |

| Manufacture | Module Model / Series |
|---|---|
| Axitec | AC-xxx(M/P)/60S, AC-xxx(M/P)/72S<br>AC-xxxMH/120(S/V/SB/VB)<br>AC-xxxMH/144(S/V/SB/VB)<br>AC-xxxP/156-60S<br>AC-xxxTGB/108BB<br>AC-xxxTGB/144TS<br>AC-xxxTGB/144WS-US<br>AC-xxxTGB/96BB |
| Bluesun Solar | HEX5 BSMxxxM10-54HPH<br>BSMxxxM10-72HBD |
| Boviet Solar | BVM6610<br>BVM6610M-xxxS-H-HC<br>BVM6610M-xxxS-H-HC-BF<br>BVM6612<br>BVM6612M-xxxS-H-HC-BF-DG<br>BVM7612M-H-HC-BF-DG |
| BYD | P6K & MHK-36 Series |
| Canadian Solar | CS1(H/K/U/Y)-MS<br>CS3K-(MB/MB-AG/MS/P/P HE/PB-AG)<br>CS3L-(MS/P), CS3N-MS<br>CS3U-(MB/MB-AG/MS/P/P HE/PB/PB-AG)<br>CS3W-(MS/MB-AG/P/P-PB-AG)<br>CS3Y-MB-AG<br>CS5A-M<br>CS6.1-54TM-H<br>CS6.1-60TM-H<br>CS6.1-72TB-H<br>CS6.2-66TB-xxxH<br>CS6K-(M/MS/MS AllBlack/P/P HE)<br>CS6P-(M/P) |

| Manufacture | Module Model / Series |
|---|---|
| Canadian Solar(Cont.) | CS6.2-48TM-xxxH<br>CS6.2-66TB-xxxHR<br>CS6R-MS<br>CS6R-xxxMS-HL<br>CS6U-(M/P/P HE)<br>CS6W-(MS/MB-AG)<br>CS6W-xxx-TB-AG<br>CS6X-P, CSX-P<br>CS7L-MB-AG<br>CS7L-TB-AG<br>CS7N-xxxMB-AG<br>CS7N-xxx MS<br>CS7N-xxxTB-AG<br>ELPS CS6(A/P)-MM |
| Centrosolar America | C-Series & E-Series |
| CertainTeed | CT2xxMxx-01, CT2xxPxx-01, CTxxxMxx-01<br>CT54M10XXX-N07<br>CT72M10XXX-N07<br>CTM10400HC11-06, CTxxxHC11-06<br>CTM10400HC11-08, CTM10400HC11-09<br>CTTCxxxHC12-08<br>CTxxxMxx-04, CTxxxHC11-04<br>CTxxxPxx-01, CTxxxMxx-02, CTxxxMxx-03 |
| Eco Solargy | Orion 1000 & Apollo 1000 |
| EMMVEE | ExxxHCBG144-T<br>ExxxHCBT144-T<br>ExxxH CM120-B<br>ExxxM72-B<br>ExxxP72-B<br>Titanium Clear |
| Energy America | ZLK-xxx |

- Unless otherwise noted, all modules listed above include all wattages and specific models within that series. Variable wattages are represented as "xxx"
- Items in parenthesis are those that may or may not be present in a compatible module's model ID
- Slashes "/" between one or more items indicates that either of those items may be the one that is present in a module's model ID
- The frame profile must not have any feature that might interfere with the bonding devices that are integrated into the racking system
- Use with a maximum over current protection device OCPD of 30A
- **Listed models can be used to achieve a Class A fire system rating for steep slope and low slope applications. See page 33**

## Electrical Bonding and Grounding Test Modules

The list below is not exhaustive of compliant modules but shows those that have been evaluated and found to be electrically compatible with the SOLARMOUNT system.

| Manufacture | Module Model / Series |
|---|---|
| ET Solar | ET AC Module, ET Module<br>ET-M772BH520-550WW/WB<br>ET-M772BHxxxTW/TB<br>ET-N772TBHxxxGL |
| Fellow Energy | FE72-18X(ND) |
| First Solar | FS-6XXX(A)<br>FS-6XXX(A)-P, FS-6XXX(A)-P-I |
| Flextronics | FXS-xxxBB |
| Freedom Forever | FF-MP-BBB-xxx, FF-MP1-BBB-xxx |
| FreeVolt | PVGraf |
| GCL | GCL-P6 & GCL-M6 Series |
| Gstar Solar | GSD7S54T-xxxBT<br>GSP7G54M(H) |
| Hansol | TD-AN3, TD-AN4<br>UB-AN1, UD-AN1 |
| Hanwha SolarOne | HSL 60 |
| Heliene | 132HC M10 SL Monofacial Module<br>144HC M10 NTYP SL Bifacial<br>144HC M10 SL Bifacial<br>144HC M6<br>156HC M10 NTYP SL Bifacial<br>156HC M10 SL Bifacial<br>36M, 36P 60M, 60P, 72M & 72P Series |
| HT-SAAE | HT60-156M(V)-C<br>HT60-156M-C<br>HT72-156(M/P)<br>HT72-156M(PD)-BF<br>HT72-156M(PDV)-BF<br>HT72-156P(V)-C |

| Manufacture | Module Model / Series |
|---|---|
| HT-SAAE(Cont.) | HT72-156P-C<br>HT72-166M<br>HT72-18X<br>HT72-18X(ND)-F |
| Hyperion Solar | HY-DH108P8(B)<br>HY-DH108N8B<br>HY-DH144P8<br>HY-DH156N8<br>HY-DH156P8 |
| Hyundai | KG, MG, RW, TG, RI, RG, TI, KI, HI Series<br>HiA-SxxxHG<br>HiD-SxxxRG(BK)<br>HiN-SxxxXG(BK)<br>HiN-TxxxNF(BK)<br>HiN-TxxxNI<br>HiN-TxxxNJ<br>HiN-TxxxOJ<br>HiS-S400PI<br>HiS-SxxxGI<br>HiS-SxxxOJ<br>HiS-SxxxXG(BK)<br>HiS-SxxxYH(BK)<br>HIS-TxxxNF(BK)<br>HiS-TxxxNJ |
| Illuminate USA | IL5-72HBD-xxx M<br>IL8-66HGD-xxx M |
| Imperial Star | ISM7-SHDD108-400/M |
| INDEPWR Solar | iPWR-M10-54BX2S-xxxW<br>iPWR-M10-60BX2S-xxxW |
| ITEK | iT-SE Series |
| Japan Solar | JPS-60 & JPS-72 Series |

| Manufacture | Module Model / Series |
|---|---|
| JA Solar | ** = Backsheet, ## Cell technology<br>i. ##: 01, 02, 03, 09, 10<br>ii. **: SC, PR, BP, HiT, IB, MW, MR<br>JAM54D41-xxx/MB<br>JAM54S30 xxx/MR<br>JAM54S31 xxx/MR<br>JAM6(k)-60-xxx/**, JAM60S##-xxx/**<br>JAM6(K)-60/xxx, JAP6(k)-72-xxx/4BB<br>JAM6(k)-72-xxx/**, JAM72S##-xxx/**<br>JAM66D45 LB<br>JAM72D10 xxx/MB<br>JAM72D30MB<br>JAM72D40 xxx/MB<br>JAM72S30 /MR<br>JAM78D10MB<br>JAP6(k)-60-xxx/4BB, JAP60S##-xxx/**<br>JAP6 60-xxx<br>JAP72S##-xxx/** |
| Jinko | JKM & JKMS Series<br>JKMxxxM-6RL3-B<br>JKMxxxM-72HBL-V<br>JKMxxxM-72HL4-(T)V<br>JKMxxxM-72HL4-TV<br>JKMxxxM-72HLM-TV<br>JKMxxxM-72HL-V<br>JKMxxxM-7RL3-TV<br>JKMxxxM-7RL3-V<br>JKMxxxN-54HL4-B<br>JKMxxxN-72HL4-BDX<br>JKMxxxN-72HL4-TV<br>JKMxxxN-72HL4-BDV (30mm & 35mm Frame Height) |
| Kyocera | KD-F & KU Series |

- Unless otherwise noted, all modules listed above include all wattages and specific models within that series. Variable wattages are represented as "xxx"
- Items in parenthesis are those that may or may not be present in a compatible module's model ID
- Slashes "/" between one or more items indicates that either of those items may be the one that is present in a module's model ID
- The frame profile must not have any feature that might interfere with the bonding devices that are integrated into the racking system
- Use with a maximum over current protection device OCPD of 30A
- **Listed models can be used to achieve a Class A fire system rating for steep slope and low slope applications. See page 33**

## Electrical Bonding and Grounding Test Modules

The list below is not exhaustive of compliant modules but shows those that have been evaluated and found to be electrically compatible with the SOLARMOUNT system.

| Manufacture | Module Model / Series |
|---|---|
| LA Solar | LSxxxBF<br>LSxxxBL<br>LSxxxBL (410 watt)<br>LSxxxHC(166)<br>LSxxxHC (430-450 watt range)<br>LSxxxHC, BLA Model |
| LG Electronics | LGxxx(E1C/E1K/N1C/N1K/N2T/N2W/S1C/S2W/Q1C/Q1K)-A5<br>LGxxx(A1C/M1C/M1K/N1C/N1K/Q1C/Q1K/QAC/QAK)-A6,<br>LGxxxN2W-B3<br>LGxxxN2T-B5<br>LGxxxN1K-B6<br>LGxxx(N1C/N1K/N2T/N2W)-E6<br>LGxxx(N1C/N1K/N2W/S1C/S2W)-G4<br>LGxxxN2T-J5, LGxxx(N1K/N1W/N2T/N2W)-L5<br>LGxxx(M1C/N1C/Q1C/Q1K)-N5<br>LGxxx(N1C/N1K/N2W/Q1C/Q1K)-V5<br>LGxxxN3K-V6 |
| LONGi | LR4-60(HPB/HPH)<br>LR4-72(HPH)<br>LR4-72HBD xxxM<br>LR5-54HABB-xxx M<br>LR5-54-HPB-xxx M<br>LR5-54HTB xxxM<br>LR5-72HBD xxx M<br>LR6-60<br>LR6-60(BK/HPB/HPH/HV/PB/PE/PH)<br>LR6-72<br>LR6-72(BK/HV/PB/PE/PH)<br>LR7-72HGD-xxx M |

| Manufacture | Module Model / Series |
|---|---|
| LONGi(Cont.) | LR8-54HGBB<br>LR8-66HGD-xxx M<br>RealBlack LR4-60HPB<br>RealBlack LR6-60HPB |
| Maxeon | SPR-MAX3-xxx-COM<br>SPR-MAX3-xxx-R<br>SPR-MAX3-xxx-BLK-R<br>SPR-MAX6-xxx<br>SPR-MAX6-xxx-BLK |
| Meyer Burger | Meyer Burger Black<br>Meyer Burger White<br>Meyer Burger Glass |
| Mission Solar Energy | MSE Mono, MSE Perc<br>MSExxx(SR8T/SR8K/SR9S/SX5T)<br>MSExxx(SX5K/SX6W)<br>MSExxxHT0B<br>MSExxxSX6Z<br>MSExxxSX9R<br>MSExxxSX9Z<br>MSH10-xxxHN4G<br>MSH10-xxxHT4T<br>MSI10-xxxHN4G<br>MSI10-xxxHT4G<br>MSI10-xxxHT4T<br>MSN10xxxHT4T<br>MSX10-xxxHN0B |
| Mitrex | Mxxx-L3H, Mxxx-I3H |
| Mitsubishi | MJE & MLE Series |
| mSolar | 108BB HC Series (TXI10-xxx108BB)<br>144BB HC Series (TXS6-xxx144BB) |

| Manufacture | Module Model / Series |
|---|---|
| Neo Solar Power Co. | D6M Series |
| NE Solar | NESE xxx-60MH-M6<br>NESE xxx 66MHB-G12<br>NESE xxx-72MHB-M10<br>NESE xxx 72MHT-M10<br>NESE xxx 72THB-M10<br>NESE xxx 72MHB-M10 |
| Panasonic | VBHNxxxSA06/SA06B/SA11/SA11B<br>VBHNxxxSA15/SA15B/SA16/SA16B,<br>VBHNxxxKA, VBHNxxxKA03/04,<br>VBHNxxxSA17/SA17G/SA17E/SA18/SA18E,<br>VBHNxxxZA01/ZA02/ZA03/VBHNxxxZA04<br>EVPVxxx<br>EVPVxxx(H/K/PK/HK/HK2) |
| Peimar | SGxxxM (FB/BF)<br>SMxxxM |
| Philadelphia Solar | PS-M108(HCBF)-400W (30 & 35mm frames)<br>PS-M144(HCBF)-xxxW<br>PS-MNB108(HCBF)-xxxW<br>PS-MNB144(HCBF)-xxxW<br>PS-MNB156(HCBF)-xxxW |
| Phono Solar | PSxxxM1-20/U<br>PSxxxM1H-20/U<br>PSxxxM1-20UH<br>PSxxxM1H-20UH<br>PSxxxM4(H)-24/TH<br>PSxxxM1-20/UH<br>PSxxxM1H-20/UH<br>PSxxxM-24/T |

- Unless otherwise noted, all modules listed above include all wattages and specific models within that series. Variable wattages are represented as "xxx"
- Items in parenthesis are those that may or may not be present in a compatible module's model ID
- Slashes "/" between one or more items indicates that either of those items may be the one that is present in a module's model ID
- The frame profile must not have any feature that might interfere with the bonding devices that are integrated into the racking system
- Use with a maximum over current protection device OCPD of 30A
- **Listed models can be used to achieve a Class A fire system rating for steep slope and low slope applications. See page 33**

## Electrical Bonding and Grounding Test Modules

The list below is not exhaustive of compliant modules but shows those that have been evaluated and found to be electrically compatible with the SOLARMOUNT system.

| Manufacture | Module Model / Series |
|---|---|
| Phono Solar | PSxxxMH-24/T<br>PSxxxM-24/TH<br>PSxxxMH-24/TH |
| Prism Solar | P72 Series, P72X-xxx |
| Q Cells | Peak G5(SC) , G6(+)(SC)(AC), G7, G8(+),<br>Peak L-G5, L-G6, L-G7, L-G8(BFF)<br>Plus, Pro, Peak, G3, G4,<br>Plus, Pro, Peak L-G2, L-G4, L-G5<br>Q.PEAK DUO( BLK)-G6+<br>Q.PEAK DUO (BLK)-G7<br>Q.PEAK DUO (BLK) G8(+)<br>Q.PEAK DUO (BLK) ML-G10(a)(+)<br>Q.PEAK DUO (BLK) ML-G9(+)<br>Q.PEAK DUO BLK G10(+)<br>Q.PEAK DUO BLK G10+ /AC<br>Q.PEAK DUO BLK-G6+/TS<br>Q.PEAK DUO BLK ML-G10+/AC<br>Q.PEAK DUO BLK ML-G10.B+<br>Q.PEAK DUO BLK ML-G10.C+<br>Q.PEAK DUO BLK ML-G10.C1+/AC<br>Q.PEAK DUO BLK ML-G10+ / t<br>Q.PEAK DUO BLK ML-G10+ / TS<br>Q.PEAK DUO-G10+<br>Q.PEAK DUO L-(G7/G7.1/G7.2/G7.3/G7.7)<br>Q.PEAK DUO L-(G8/G8.1/G8.2/G8.3)<br>Q.PEAK DUO L-G6.3 / BFG<br>Q.PEAK DUO L-G8.3 (BFF/BFG/BGT)<br>Q.PEAK DUO ML-G12S.3/BFG<br>Q.PEAK DUO ML-G12S.3 / BFG<br>Q.PEAK DUO ML-G12S.7/BFG<br>Q.PEAK DUO ML-G12S.d / BFG |

| Manufacture | Module Model / Series |
|---|---|
| Q Cells (Cont.) | QPEAK DUO G10.C1+ AC<br>Q.PEAK DUO XL-(G10/G10.2/G10.3/G10.c/ G10.d)<br>Q.PEAK DUO XL-(G11.2/G11.3)<br>Q.PEAK DUO XL-(G9/G9.2/G9.3)<br>Q.PEAK DUO XL-G10.3/BFG<br>Q.PEAK DUO XL-G10.d/BFG<br>Q.PEAK DUO XL-G11.3/BFG<br>Q.PEAK DUO XL-G11S.3 / BFG<br>Q.PEAK DUO XL-G9.3/BFG<br>Q.TRON BLK M-G2+<br>Q.TRON BLK M-G2(.H1)(.F1)(.C1)+/AC<br>Q.TRON BLK M-G2+ AC<br>Q.TRON BLK M-G2.C+<br>Q.TRON BLK M-G2.F+<br>Q.TRON BLK M-G2.F1+/AC<br>Q.TRON BLK M-G2.H+<br>Q.TRON BLK M-G2.H1+/AC<br>Q.TRON BLK M-G2+ SERIES<br>Q.TRON M-G2+ SERIES<br>Q.TRON ML-G3.3/BFG<br>Q.TRON XL-G2.3 / BFG<br><br>Q.PEAK DUO BLK ML-G10.XY+/AC<br>(where “X” = any letter between A to W,<br>where “Y” = any number between 1 to 9.) |

| Manufacture | Module Model / Series |
|---|---|
| REC | RECxxxAA (BLK/Pure/Pure-R/ Pure-RX/ Pure 2/ Pro M)<br>RECxxxNP (N-PEAK)<br>RECxxxNP2 (Black)<br>RECxxxNP3 Black<br>RECxxxPE, RECxxxPE72<br>RECxxxTP, RECxxxTP72<br>RECxxxTP2(M/BLK2)<br>RECxxxTP2S(M)72<br>RECxxxTP3M (Black)<br>RECxxxTP4 (Black)<br>RECxxxAA Pure-RX |
| Renesola | All 60-cell modules<br>RS6-xxxNBG-E3 |
| Risen | RSM Series, RSM110-8-xxxBMDG |
| SEG Solar | SEG-xxx-BMD-HV<br>SEG-xxx-BMD-TB, SEG-xxx-BMB-TB<br>SEG-xxx-BMA-HV, SEG-xxx-BMA-TB<br>SEG-xxx-BMB-HV, SEG-xxx-BMA-BG<br>SEG-xxx-BMB-BG, SEG-xxx-BTA-BG<br>SEG-xxx-BTB-BG, SEG-xxx-BMD-BG<br>SEG-xxx-BTD-BG |
| S-Energy | SL40-60MAI/MBI/MCI-xxxV<br>SL45-60BGI/BHI<br>SL45-60MBI-xxxZ<br>SN72 & SN60 Series |

- Unless otherwise noted, all modules listed above include all wattages and specific models within that series. Variable wattages are represented as "xxx"
- Items in parenthesis are those that may or may not be present in a compatible module's model ID
- Slashes "/" between one or more items indicates that either of those items may be the one that is present in a module's model ID
- The frame profile must not have any feature that might interfere with the bonding devices that are integrated into the racking system
- Use with a maximum over current protection device OCPD of 30A
- **Listed models can be used to achieve a Class A fire system rating for steep slope and low slope applications. See page 33**

## Electrical Bonding and Grounding Test Modules

The list below is not exhaustive of compliant modules but shows those that have been evaluated and found to be electrically compatible with the SOLARMOUNT system.

| Manufacture | Module Model / Series |
|---|---|
| Seraphim | SEG-(6PA/6PB/6MA/6MA-HV/6MB/E01/E11)<br>SRP-(6QA/6QB)<br>SRP-320-375-BMB-HV<br>SRP-390-405-BMD-HV<br>SRP-390-450-BMA-HV<br>SRP-xxx-6MB-HV<br>SRP-xxx-BMC-HV<br>SRP-xxx-BMD-HV<br>SRP-xxx-BMZ-HV<br>SRP-xxx-BTA-BG<br>SRP-xxx-BTB-BG<br>SRP-xxx-BTC-BG<br>SRP-xxx-BTD-BG<br>SRP-xxx-BTE-BG |
| Sharp | NU-SA & NU-SC Series |
| Silfab | SLA-M, SLA-P, SLG-M, SLG-P & BC Series<br>SIL-xxx(BG/BK/BL/HC/HC+/HL/HM/HN/ML/NL/NT/NX/NU)<br>SIL-xxx QD<br>SIL-xxx QM<br>SIL-xxx XL<br>SIL-xxx XM<br>SIL-xxx XM+ |
| Sirius | ELNSM54M-HC-BF Series<br>ELNSM54M-HC-N<br>ELNSM54M-HC Series<br>ELNSM72M-HC Series |

| Manufacture | Module Model / Series |
|---|---|
| Solar4America | S4Axxx-108MH10BB<br>S4Axxx-72MH5BB<br>S4Axxx-144MH10xxx<br>S4Axxx-144TH10xxx<br>S4Axxx-144TH16xxx<br>S4Axxx-108MH10xxx<br>S4Axxx-108TH10xxx |
| SolarEver USA | SE-166*83-xxxM-120N<br>SE-182*105-xxxM-96-BD<br>SE-182*91-xxxM-108N |
| Solaria | PowerXT-xxxR-(AC/PD/BD)<br>PowerXT-xxxC-PD<br>PowerXT-xxxR-PM (AC)<br>PowerX-400R |
| Solar Space | SS8-54HDB-xxx-N<br>SS8-54HD-xxx-N<br>SS8-72HD-xxx-M<br>SS8-72HD-xxx-N<br>SS8-78HD-xxx-M<br>SS9-66HD-xxx-N<br>SSA-48HDB-xxx-N<br>SSA-48HD-xxx-N<br>SSA-54HDB-xxx-N<br>SSA-54HD-xxx-N<br>SSA-66HD-xxx-N |
| Solartech | STU HJT, STU PERC & Quantum PERC |
| SolarWorld | Sunmodule Protect, Sunmodule Plus/Pro |
| Sonali | SS-M-360 to 390 Series<br>SS-M-390 to 400 Series<br>SS-M-440 to 460 Series<br>SS-M-430 to 460 BiFacial Series |

| Manufacture | Module Model / Series |
|---|---|
| Sun Edison | F-Series, R-Series |
| Suniva | MV Series & Optimus Series (35mm) |
| Sunmac Solar | M754SH-BB Series |
| SunPlus Optimum | SR4-54HTB-xxxM |
| SunPower | AC, X-Series, E-Series & P-Series<br>SPR E20 435 COM (G4 Frame)<br>Axxx-BLK-G-AC, SPR-Mxxx-H-AC<br>SPR-Mxxx-H-AC, SPR-Mxxx-BLK-H-AC |
| Sunpro Power | SPDGxxx-120M12<br>SPDGxxx-N108M10<br>SPDGxxx-N144M10 |
| SunTech | STP, STPXXXS - B60/Wnhb |
| Talesun | Hipor M, Smart,<br>TD6I72M, TD7G72M, TP572, TP596, TP654, TP660, TP672, TP6L72M-450, TP7G54M(H),<br>TM7G54M<br>TM3G48M<br>TM7G60M<br>TM3G54M<br>TM7G72M<br>TM3G66M<br>TP6F72M<br>TP6F72M(H) |
| Tesla | SC, SC B, SC B1, SC B2,<br>TxxxS, TxxxH<br>Tesla Solar Panel<br>TSP-415/TSP-420 |

- Unless otherwise noted, all modules listed above include all wattages and specific models within that series. Variable wattages are represented as "xxx"
- Items in parenthesis are those that may or may not be present in a compatible module's model ID
- Slashes "/" between one or more items indicates that either of those items may be the one that is present in a module's model ID
- The frame profile must not have any feature that might interfere with the bonding devices that are integrated into the racking system
- Use with a maximum over current protection device OCPD of 30A
- **Listed models can be used to achieve a Class A fire system rating for steep slope and low slope applications. See page 33**

## Electrical Bonding and Grounding Test Modules

The list below is not exhaustive of compliant modules but shows those that have been evaluated and found to be electrically compatible with the SOLARMOUNT system.

| Manufacture | Module Model / Series |
|---|---|
| Thornova | TS-BG54<br>TS-BG72<br>TS-BBT54(xxx)<br>TS-BGT72(xxx) |
| TP Solar | TPxxxVG12R16NB |
| Trina Solar | DE09C.07<br>DEG15HC.20(II), DEG15MC.20(II)<br>DEG15VC.20(II), DE18M(II), DEG18MC.20(II)<br>DE19, DEG19C.20<br>PA05, PD05, DD05, DD06, DE06, DE09.05<br>PD14, PE14, DD14, DE14, DE15, DE15V(II)<br>TSM-DE06X.05(II)<br>TSM-DE09.05<br>TSM-DE09.08<br>TSM-DE09C.07,<br>TSM-DE15H(II)<br>TSM-DEG21C.20<br>TSM-NE09RC.05<br>TSM-NE09RH.05<br>TSM-NE19RC<br>TSM-NEG19RC.20<br>TSM-NEG21C.20<br>TSM-NEG9RH.25 |
| TSMC | TS-150C2 CIGSw |
| Universal Solar | UNI4xx-144BMH-DG<br>UNI5xx-144BMH-DG<br>UNIxxx-108M-BB<br>UNIxxx-120M-BB<br>UNIxxx-120MH |
| Upsolar | UP-MxxxP, UP-MxxxM(-B) |

| Manufacture | Module Model / Series |
|---|---|
| URECO | D7Kxxx(H7A/H8A), D7Mxxx(H7A/H8A)<br>F6MxxxE7G-BB<br>FAKxxx(C8G/E8G), FAMxxxE7G-BB<br>FAMxxxE8G(-BB), FBKxxxM8G<br>FBMxxxM7G-BB<br>FBMxxxMFG-BB |
| Vikram Solar | Eldora, Somera, Ultima<br>PREXOS VSMDHT.60.AAA.05<br>PREXOS VSMDHT.72.AAA.05<br>Paradea VSMDH.72.AAA.05 |
| Vina | VNS-72M1-5-xxxW-1.5,<br>VNS-72M3-5-xxxW-1.5,<br>VNS-144M1-5-xxxW-1.5,<br>VNS-144M3-5-xxxW-1.5,<br>VNS-120M3-5-xxxW-1.0 |
| VSUN | VSUN4xx-144BMH<br>VSUN4xx-144BMH-DG<br>VSUN5xx-144BMH-DG<br>VSUNxxx-108BMH<br>VSUNxxx-108M-BB<br>VSUNxxx-108MH<br>VSUNxxx-120BMH<br>VSUNxxx-120M-BB<br>VSUNxxx-132BMH<br>VSUNxxx-144BMH,<br>VSUNxxx-144M-BB<br>VSUNxxx-144M-BW<br>VSUNxxx-144MH<br>VSUNxxx-60M-BB<br>VSUNxxx-72MH |

| Manufacture | Module Model / Series |
|---|---|
| VSUN(Cont.) | VSUNxxxN-108BMH-BB<br>VSUNxxxN-108BMH-BB (SoftPaw)<br>VSUNxxxN-120BMH-BB (SoftPaw)<br>VSUNxxxN-144BMH,<br>VSUNxxxN-144BMH-DG<br>VSUNxxxN-144MH |
| Waaree | Ahnay Series Bi-33<br>Arka Series WSMDi<br>Bi-55-xxx<br>BiN-08-xxx |
| Winaico | WST & WSP Series |
| Yingli | YGE & YLM Series |
| Yotta Energy | YSM-B450-1 |
| ZNShine | ZXM6-72 Series<br>ZXM6-NH120 Series<br>ZXM6-NH144<br>ZXM6-NHLDD144<br>ZXM7-SH108 Series<br>ZXM7-SHDB144<br>ZXM7-SHLDD144<br>ZXM7-UHLDD108<br>ZXM7-UHLDD144<br>ZXM8-GPLDD132 Series<br>ZXM8-TPLDD132 |

- Unless otherwise noted, all modules listed above include all wattages and specific models within that series. Variable wattages are represented as "xxx"
- Items in parenthesis are those that may or may not be present in a compatible module's model ID
- Slashes "/" between one or more items indicates that either of those items may be the one that is present in a module's model ID
- The frame profile must not have any feature that might interfere with the bonding devices that are integrated into the racking system
- Use with a maximum over current protection device OCPD of 30A
- **Listed models can be used to achieve a Class A fire system rating for steep slope and low slope applications. See page 33**




INSTALL **FLASH**KIT PRO FLASHING




INSTALL L-FOOT




ATTACH L-FOOT TO RAIL

## PRE-INSTALL

- Locate roof rafters and snap chalk lines to mark the installation point for each roof attachment.
- Drill a 7/32" pilot hole at each roof attachment. Fill each pilot hole with sealant.

## STEP 1 INSTALL **FLASH**KIT PRO FLASHING

- Add a U-shaped bead of roof sealant to the underside of the flashing with the open side of the U pointing down the roof slope. Slide the aluminum flashing underneath the row of shingles directly up slope from the pilot hole as shown. Align the indicator marks on the lower end of the flashing with the chalk lines on the roof to center the raised hole in the flashing over the pilot hole in the roof. When installed correctly, the flashing will extend under the two courses of shingles above the pilot hole.

## STEP 2 INSTALL L-FOOT


- Fasten L-foot and Flashing into place by passing the included lag bolt and pre-installed stainless steel-backed EPDM washer through the L-foot EPDM grommet, and the raised hole in the flashing, into the pilot hole in the roof rafter.
- Drive the lag bolt down until the L-foot is held firmly in place. It is normal for the EPDM on the underside of the stainless steel backed EPDM washer to compress and expand beyond the outside edge of the steel washer when the proper torque is applied.

**TIP:**

- Use caution to avoid over-torqueing the lag bolt if using an impact driver.
- Repeat Steps 1 and 2 at each roof attachment point.

## STEP 3 ATTACH L-FOOT TO RAIL

- Insert the included 3/8"-16 T-bolts into the lower slot on the Rail (sold separately), spacing the bolts to match the spacing between the roof attachments.
- Position the Rail against the L-Foot and insert the threaded end of the T-Bolt through the continuous slot in the L-Foot. Apply anti-seize to bolt threads to prevent galling of the T-bolt and included 3/8" serrated flange nut. Place the 3/8" flange nut on the T-bolt and finger tighten. Repeat STEP 3 until all L-Feet are secured to the Rail with a T-bolt. Adjust the level and height of the Rail and torque each bolt to 30ft-lbs.




## PRE-INSTALL

Snap chalk lines for attachment rows. On shingle roofs, snap lines 1-3/4" below upslope edge of shingle course. Locate rafters and mark attachment locations.

At each location, drill a 7/32" pilot hole. Clean roof surface of dirt, debris, snow, and ice. Next, BACKFILL ALL PILOT HOLES WITH SEALANT.

NOTE: Space mounts per racking system install specifications.



## STEP 1: SECURE

Place **FLASH**LOC over pilot hole with lag on down-slope side. Align indicator marks on sides of mount with chalk line. Pass included lag bolt and sealing washer through **FLASH**LOC into pilot hole. Drive lag bolt until mount is held firmly in place.

NOTE: The EPDM in the sealing washer will expand beyond the edge of the metal washer when proper torque is applied.



## STEP 2: SEAL

Insert tip of UNIRAC provided sealant into port. Inject until sealant exits both vents. Follow sealant manufacturer's instructions. Follow sealant manufacturer's cold weather application guidelines, if applicable.

Continue array installation, attaching rails to mounts with provided T-bolts.




NOTE: When **FLASH**LOC is installed over gap between shingle tabs or vertical joints, fill gap/joint with sealant between mount and upslope edge of shingle course.

**USE ONLY UNIRAC APPROVED SEALANTS:** Chemlink Duralink 50, Chemlink M-1, Geocel 4500, or Geocel S-4





## PRE-INSTALL CLEAN SURFACE AND MARK LOCATION

Ensure existing roof structure is capable of supporting loads prescribed in Flashloc Duo D&E Guide. Clean roof surface of dirt, debris, snow and ice.

Snap chalk lines for attachment rows. On shingle roofs, snap lines 1/4” below upslope edge of shingle coarse. This line will be used to align the upper edge of the mount.

NOTE: Space mounts per span charts found in Flashloc Duo D&E Guide.



## STEP ONE: SECURE

ATTACHING TO A RAFTER: Place FLASHLOC DUO over rafter location and align upper edge of mount with horizontal chalk line. Secure mount with the two (2) provided rafter screws. BACKFILL ALL PILOT HOLES WITH SEALANT.

ATTACHING TO SHEATHING: Place FLASHLOC DUO over desired location and align upper edge of mount with horizontal chalk line. Secure mount with the two (2) provided rafter screws. Next, secure mount with four (4) deck screws by drilling through the FLASHLOC DUO deck mount hole locations. Unirac recommends using a drill as opposed to an impact gun to prevent over-tightening or stripping roof sheathing.

IMPORTANT: SECURELY ATTACH MOUNT BUT DO NOT OVERTIGHTEN SCREWS.



## STEP TWO: SEAL

Insert tip of UNIRAC approved sealant into port and inject until sealant exits vent.
Continue array installation, attaching rails to mounts with provided T-bolts. Follow sealant manufacturer's instructions. Follow sealant manufacturer's cold weather application guidelines, if applicable.


NOTE: When FLASHLOC DUO is installed over gap between shingle tabs or vertical joints, fill gap/joint with sealant between mount and upslope edge of shingle course.




CUT SHINGLES AS REQUIRED: DO NOT INSTALL THE FLASHLOC SLIDER ACCROSS THICKNESS VARIATIONS GREATER THAN 1/8" SUCH AS THOSE FOUND IN HIGH DEFINITION SHINGLES.

NOTE: When installing included rail attachment hardware, torque T-bolt nut to 30 ft-lbs.
NOTE: If an exploratory hole falls outside of the area covered by the sealant, flash hole accordingly.


USE ONLY UNIRAC APPROVED SEALANTS. PLEASE CONTACT UNIRAC FOR FULL LIST OF COMPATIBLE SEALANTS.




**STEP 1**: Position clamp to align T-bolt with rail slot. Lower clamp and Insert T-bolt into rail slot.




**STEP 2**: Rotate clamp clockwise 2/3 of a turn to engage T-bolt inside rail slot.





**STEP 3**: Place module at least 3/4" from end of rail and position clamp against module frame.




**STEP 4**: While applying pressure to hold the clamp against the module, push down on the module side of the clamp cap.




**STEP 5**: When the cap contacts the module frame, release and it will re-engage to the clamp base.




**STEP 6**: Tighten bolt and torque to 15 ft-lbs.

**NOTE - Universal AF End Clamps are single use.**





**STEP 7**: Confirm clamp is engaged in correct module height position and that the top of the cap is sitting level with the module frame.


**NOTE: When installing 46mm modules, loosen bolt by 1 turn before positioning clamp against module frame. Do not force clamp onto module frame as this may damage the bonding pin.**




**STEP 1**: Position clamp to align T-bolt with rail slot. Lower clamp and insert T-bolt into rail slot




**STEP 2**: Rotate clamp clockwise 2/3 of a turn to engage T-bolt inside rail slot.



**STEP3**: Slide clamp into position against module.




**STEP 4**: Place second module.




**STEP 5**: Tighten bolt and torque to 15 ft-lbs.

**NOTE - Universal AF Mid Clamps are single use.**




**NOTE: If excessive force is applied in step 2, the cap may over-rotate causing it to be mis-aligned with the module frame. If this occurs, keep rotating the cap clockwise until it returns to the original position.**


**S-5! COMPONENTS**




**S-5-B**




**S-5-B Mini**




**S-5-E**




**S-5-E Mini**




**S-5-H**




**S-5-H mini**




**S-5-H90**




**S-5-H90 Mini**




**S-5-N**




**S-5-N Mini**




**S-5-Q**




**S-5-Q Mini**



**S-5-S**




**S-5-S Mini**




**S-5-T**


**S-5! COMPONENTS**





**S-5-T mini**





**S-5-U**





**S-5-U Mini**





**S-5-V**





**S-5-V Mini**




**S-5-Z**





**S-5-Z mini**




**Protea Bracket**

## S-5! STANDING SEAM CLAMPS AND PROTEA BRACKET INSTALLATION

**STEP 1:** Follow the instructions provided on ***https://buys-5.com/*** for installing the S-5! standing seam clamps and Protea bracket on the metal roof.



***Fig A***



***Fig B***

### STEP 2: POSITION L-FOOT

Position L-foot on S-5-H90 Mini clamp or S-5-H90 clamp to align holes as shown in Fig A and Fig B respectively.

Similarlly, position L-Foot on any S-5! clamps mentioned on ***pages 45 & 46***








### STEP 3: SECURE L-FOOT

Use M8-1.25 x 17 mm bolt to secure the L-Foot to the clamp.

**Torque bolt to 13 ft-lbs**


**NOTE:**
**It is recommended to maintain least possible distance between the upright leg of the L-foot and the bolt center.**





### STEP 4: SECURE RAIL TO L-FOOT OR PROTEA BRACKET

Follow the steps mentioned on ***page 24*** to secure Rail to L-Foot or Protea Bracket



### STEP 5: COMPLETE SYSTEM INSTALLATION

Complete the SolarMount installation as per instructions in previous sections of the installation manual based on the type of clamps and specific components being installed. Ensure the system is properly grounded and bonded as per the Bonding Connections Ground Paths section that applies to your installation.




**MARK ARRAY LOCATION:**

- Clean the roof surface. Remove all dirt, debris, snow, and ice.
- Mark the array layout on the roof and determine roof attachment locations based on the array layout.
- Snap chalk lines to define each row of attachment points.
- For shingle roofs, snap chalk lines 1/4 in. below the upslope edge of the shingle course.
- Locate rafters and mark their positions at the intersection with the chalk lines.
- Verify attachment spacing per the Design and Engineering Guide or project-specific U-Builder Engineering Report.

**PRO TIP**


**Install the attachment within 1/4" of the chalkline to allow the rail to slide freely in the rail clamp.**

**⚠ WARNING**

- **To maintain butyl flashing performance, Unirac does not recommend installing when ambient and/or roof temperatures are below 0°F or above 180°F.**
- **SM Butyl must be installed on a clean, dry surface to ensure flashing integrity.**

NOTE:

- SM Butyl is designed for use on Asphalt Shingle, Rolled Comp, EPDM, TPO, Polyethylene, Polypropylene, ABS, and Metal Roofs (including Galvalume, painted steel, and galvanized).
- Pilot holes are not necessary to be drilled for self-drilling screws. If holes are drilled to identify the rafter, they should be backfilled with sealant before installing the attachment.
- SM Butyl attachments are designed for slopes ranging from 0 to 90-degrees. For installations over 45-degrees, contact Unirac engineering for design guidance.




**PLACE SM BUTYL ATTACHMENT WITH BUTYL BASE:**

- Identify the position of the attachment to install before peeling the release paper.
- Ensure that the attachment lands on a flat surface. If the surface at the location of the attachment is uneven, add butyl patches to flatten the surface.

**NOTE:**
**See Pages 50 to 52 for instructions on rafter vs. decking installation and which screw holes to use**


**⚠ CAUTION**

**Do not peel the release paper from the butyl on attachment before identifying the position of attachment to install.**

**⚠ WARNING**

- **Do not install the attachment on uneven surfaces or shingle overlaps greater than 1/8".**
- **Uneven mounting surfaces can create voids between the adhesive and the roof, increasing the risk of water leakage.**

**NOTE:**
**See Page 53 for instructions on placing extra butyl pads or contact Unirac team for further information.**




**INSTALL SM BUTYL ATTACHMENT WITH BUTYL BASE TO RAFTER:**


- Peel off the release liner from the underside of the attachment.
- Place the SM Butyl attachment over the rafter location and align the edge of the mount with the horizontal chalk line.
- Secure the attachment by installing two (2) provided rafter screws through the designated rafter holes into the rafter.

**NOTE:**
**Ensure to use drill extension or deep socket tool for installing rafter screws.**

**⚠ CAUTION**

- ***To determine if the screw is engaging the rafter, there should be resistance to driving the screw through the entire length. If the screws do not properly engage the rafter, refer to the pro tip in Page 51.***
- ***It is recommended to begin installation with the screws on the uphill side of the attachment and continue installing the screws on the downhill side of the attachment for best fit.***


**⚠ WARNING**




**Do not over-torque the structural screw.**
**When proper torque is applied, the EPDM washer should slightly expand out from the sides as shown in the image.**

**PRO TIP:**


***If you miss the rafter while driving the first screw and the rafter is on the edge of the attachment, then follow the steps below:***





- Install a second screw in the adjacent hole closest to the rafter center.
- If the second screw engages the rafter, install the corresponding third screw into the rafter and proceed with standard installation.




- If the second screw does not engage the rafter, install a third screw on the same uphill side.
- If the third screw engages the rafter, install the corresponding fourth screw into the rafter and and proceed with standard installation.




- If the rafter is not engaged after the third screw, follow the direct-to-deck installation procedure and reduce attachment spacing per Unirac direct-to-deck span requirements.




**INSTALL SM BUTYL ATTACHMENT WITH BUTYL BASE TO DECK (DIRECT TO DECK):**

- When installing the attachment directly to the roof deck (not to a rafter), install four (4) screws on attachment.
- Install screws in any four (4) attachment holes.


**Note:**


- **Additional deck screws are NOT included in the KIT. Must be purchased separately.**
- **Maintain stock of additional deck screws from Unirac Kits in case of direct-to-deck installation.**


**⚠ CAUTION**


1. **Allowable attachment spans may change for direct-to-deck applications.**
2. **Unirac recommended spans are only valid with Unirac supplied screws.**

## INSTALL SM BUTYL DTD BUTYL ATTACHMENT ON SHINGLE OVERLAP (> 1/8" THICKNESS)




If the attachment falls over a shingle overlap having thickness over 1/8", level the surface by following below steps:


A. Measure the attachment overhang.
B. Cut the butyl pads to required size.
C. Stack extra butyl pad layers as necessary to level the roof and place the attachment.
D. Begin installation with the screws on the uphill side of the attachment and continue to install the screws on the downhill side of the attachment.

**NOTE:**

- **Extra Butyl Patches (XTRABUTL/-US) are not required when installing the SM Butyl Attachment on shingle steps or courses with a thickness up to 1/8".**
- **Extra butyl pads are NOT included in the KIT.**
- **Pre-stock with extra butyl pads from Unirac Kits in case installation is required over overlap or gap.**

**⚠ WARNING**


- **Do not install the attachment on uneven surfaces or shingle overlaps greater than 1/8".**
- **Uneven mounting surfaces can create voids between the adhesive and the roof, increasing the risk of water leakage and rail clamp misalignment.**





## INSTALL SM BUTYL DTD BUTYL ATTACHMENT ON SHINGLE COURSE OVERLAP (> 1/8" THICKNESS)

### CASE 1: PREVENT EXTRA BUTYL PADS USAGE

- If the attachments overlap from one shingle course to the next shingle course in a rail-based system, reposition the attachment by moving up or down the shingle course along the same rafter line to avoid butyl layering.










**NOTE:**


- **Additional butyl layering is not required while installing attachment over a gap in the same shingle course**

### CASE 2: SHINGLE COURSES REQUIRES ADDITIONAL BUTYL PADS












If the attachment falls over a shingle overlap having thickness over 1/8", level the surface by following below steps:

A. Measure the attachment overhang.
B. Cut the butyl pads to required size.
C. Stack extra butyl pad layers as necessary to level the roof and place the attachment.
D. Begin installation with the screws on the uphill side of the attachment and continue to install the screws on the downhill side of the attachment.





**WARNING**

**Installing attachments on uneven surfaces or shingle overlaps greater than 1/8" creates a risk for water leakage and rail clamp misalignment due to gap created between the adhesive and roof surface.**