



March 1, 2024

Quick Instructions for SolarHook Tile Replacement Flashing Application

For optimum SOLARHOOK Tile Replacement Flashing application, Unirac requires cutting a slit on the flashing where it meets with the SOLARHOOK. This ensures a minimum gap between the flashing and the surrounding tiles, providing the best fit and aesthetics.

Follow these simple steps for an easy installation process:

STEP 1 – Position SOLARHOOK Tile Replacement Flashing where you need to replace a tile, and mark where the SOLARHOOK meets the flashing. **Notice that the installer should NOT fold the tab(s) on the W- and Flat-type Flashings at this stage.**





STEP 2 – Cut marked area on the SOLARHOOK Tile Replacement Flashing. Fold the flashing to create slit.



FINAL STEP – Place SOLARHOOK Tile Replacement Flashing back on the spot with SOLARHOOK. For W- and Flat-type Tile Replacement Flashings, fold the tabs to secure flashing.



If you have any questions, please contact your Unirac sales representative. We're looking forward to seeing your success with SOLARHOOK Tile Replacement Flashing installation!